DH75 & DH100 Display Board Replacement Instructions

Approximate time to replace the board: 5 minutes

You Will Need: 1. A Phillips head screwdriver



2. Your new display board replacement kit includes:

- A T15 Torx Wrench
- Display Board & Bezel
- Instructions



Scan to Watch Video

⚠ **WARNING:** Before starting, shut off the unit and unplug the dehumidifier power cord. Failure to follow the warnings and instructions may result in electric shock and/or serious injury.

Step 1 – Using your Phillips head screwdriver, locate and unscrew the screw at the top of the filter door by a quarter turn, counterclockwise. Remove the door (Figure 1). Slide the filter out (Figure 2).



Figure 1



Figure 2

Step 2 – Using the included T15 Torx wrench, locate and unscrew the four screws holding the display board in place (Figure 3).

Step 3 – Once the board is loose, carefully unplug the two wire inserts (Figure 4). Set aside the old display board.



Figure 3



Figure 4

Step 4 – Insert the **new** display board through the open filter door and place behind the display board opening, ensuring the arrows are pointing up (Figures 5). Reconnect the two wire plugs to the new board (Figure 6).

Step 5 – Use the T15 Torx wrench to screw the 4 screws back into the new display board, holding on to the back of the board until all four screws are fully seated (Figure 7).



Figure 5



Figure 6



Figure 7

Step 6 – Re-insert the filter (Figure 8). Use the Phillips head screwdriver to re-attach and screw in the door (Figure 9). Finally, plug the unit in and adjust the settings as desired.



Figure 8



Figure 9

Step 7 (*Optional*) – If you use the GeneralAire APP to control your dehumidifier, reconnect the unit's display board to the home's 2.4 GHz Wi-Fi and connect to the GeneralAire APP using your new 6-digit pin.

Contact Tech Support at (866) 476-5101 with any questions.
General Filters, Inc. 43800 Grand River Ave. Novi, MI 48375



P/N 300-8110 Rev B